

DIRECTIONS FOR HANDLING & CLEANING FILTER BALLS



1. The filter holder is filled with two net bags, they should lie loosely and not be compacted down. One large bag is enough for 4 fillings.



2. The filter balls are to be rinsed and washed as needed. It can be seen from above when they need to be cleaned. When cleaning, they are placed in a "wash tub" and the palms are used to push out the dirt.
3. Use a degreasing agent every two months. For instance, dishwasher detergent dissolved in warm water. Leave the filter balls to lie there for 12 hours before being rinsed out.
4. Allow the balls to dry fully before using them again.
5. Filter balls can also be machine washed, 40 degrees C, no detergent, dry with spin cycle at lowest RPM.